

DUCT WORK
TO EXHAUST
FAN CONNECTS
HERE

SONIC
HORNS

SHAKER
BOX

DRIER
BOX

ACCESS
DOOR

PULLYS FOR
FLOOR SCRAPER

AUGER
DRIVE
MOTOR

DRIER HEADS

SHAKER BOX SITS ON TOP OF DRIER BOX ABOVE THIS AREA

DIVIDER WALL SITS 12" OFF FLOOR

DRIER BOX
FLOOR

AUGER
IN
FLOOR


HEAD #1

HEAD #2

HEAD #3





HEADS ATTACH TO OUTSIDE
DRIER BOX WALL

AUGER
DRIVE
MOTOR




SHAKER BOX


THIS PART PENETRATES ROOF
OF DRIER BOX AND IS CENTERED
BETWEEN HEAD SIDE OF BOX AND SHAKER BOX




Auger in
Floor





SCRAPER ON DRIER
BOX FLOOR






END VIEW
SHAKER BOX






BACK VIEW
SHAKER BOX



FRONT SIDE VIEW
SHAKER BOX



INSIDE OF SHAKER BOX